


5.5 Pump Housing Configurations

Each **ViscoTwin 70 G7** Pump Housing can be set up for a variety of configuration options to suit particular application.

Each Configuration has been uniquely identified with a series of letters and numbers that call out the specific flow direction, shaft rotation, pin positions and spindle arrangements to get the desired output.

For example, a FHO3V configuration means that the Flow Direction is Face In/Housing Out (FH), Shaft Rotation is Outward (O). Pin Position is Configuration 3 (3) with Spindle Arrangement V (V).

There are SIX possible configurations, and each one is listed in the chart below, as well on the following pages. The default configuration is FHO3V.




The TOP of the pump is always determined by the location of the VENT Plug (Pos. 2232) on the Bearing Housing, regardless of the Pump Housing orientation and the final position of the Pump.


| CONFIG. NAME | FLOW DIRECTION | SPINDLE ROTATION | PIN POSITION | SPINDLE ARRANGE- MENT | COMMENTS |
|-----------------|--------------------------|------------------|-----------------|-----------------------------|---|
| FHO3V | Face In / Housing Out | Outwards | 3 | V | Product dragged along the bottom |
| FHI1A | Face In / Housing Out | Inwards | 1 | А | Product dragged along the top |
| HFI1V | Housing In / Face Out | Inwards | 1 | V | Product dragged along the top |
| НГОЗА | Housing In / Face Out | Outwards | 3 | А | Product dragged along the bottom |
| BDB2V | Bi-Directional | Bi-Directional | 2 | V | Limited Viscosity Tapered Spindles Preferred |
| BDB2A | Bi-Directional | Bi-Directional | 2 | А | Limited Viscosity Tapered Spindles Preferred |


Page 01 PROCESSTEC INC. 2020














Page 03 PROCESSTEC INC. 2020

















Page 05 PROCESSTEC INC. 2020














Page 07 PROCESSTEC INC. 2020



